

STANDARD OPERATING PROCEDURE

Repair of Tubeless BIAS Tires

Document Number: 960C-SOP-820

Original Approval Date: Feb 04, 2010

Revision Number: 5

Page 1 of 5

Latest Revision Date: Mar 28, 2025

Next Revision Date: Mar 28, 2028

Document Approval Level: 4

This document is not controlled if printed.

REPAIR OF TUBELESS BIAS TIRES



5	APP	Mar 28, 2025	Approved	Tammy Siver	Lisa Norris	Tammy Siver
4	APP	Apr 01, 2022	Approved	L. Norris	T. Siver	T. Siver
3	APP	Mar 04, 2016	Approved	H. Lau	S. Kucher / T. Siver	G. Schreyer
Rev	Status	Rev. Date	Status Description	Prepared by	Reviewed by	Approved by

STANDARD OPERATING PROCEDURE

Repair of Tubeless BIAS Tires		Document Number: 960C-SOP-820
Original Approval Date: Feb 04, 2010	Revision Number: 5	Page 2 of 5
Latest Revision Date: Mar 28, 2025	Next Revision Date: Mar 28, 2028	Document Approval Level: 4

This document is not controlled if printed.

The following is a step-by-step procedure on how to complete a specific task or meet a facility specific requirement. Standard Operating Procedures (SOPs) are written for all identified critical tasks. By virtue of the hazard or complexity associated with critical tasks it is paramount that the SOP be followed as written. SOPs contain a listing of high-level hazards associated with the task, for detailed hazard analysis reference the applicable Task Hazard Assessments. SOPs do not replace the requirements contained in the company Standards, Codes, and Processes nor does it replace the need to comply with required legislation. Section 8.0 references documentation that the worker shall understand before work commences.

1.0 PURPOSE

- To establish a Company standard to safely and effectively carry out work as it applies to the repair of tubeless bias tires for passenger vehicles up to and including large Off-The-Road (OTR) vehicles.

2.0 SCOPE AND APPLICATION

- This document applies to all Company Heavy Construction and Mining operations. Ensure all site-specific requirements are met or exceeded before performing the task.

3.0 HAZARDS AND CONTROLS

- Uncontrolled movement of equipment.
 - Isolate all forms of hazardous energy and use wheel chocks. Follow 950C-C-028 Hazardous Energy Isolation Code.
 - Inspect equipment prior to use.
 - When using tire manipulators to install/remove tires and wheel components:
 - Do not stand in the line of fire.
 - Do not stand under manipulator arms.
 - Ensure Park brake has been set before exiting tire manipulator.
 - Follow 960C-SOP-806 Manipulator Use to Remove and Install Tire Wheel Assemblies.
- Tool failure.
 - Inspect all tools prior to task and ensure they have been calibrated as required.
 - Only use impact sockets with impact wrenches.
 - Fit test sockets on wheel nuts by hand prior to removal to ensure proper socket size.
 - Clean all studs and nuts with a wire brush prior to removal.
 - Keep work area clear of unnecessary tools and equipment.
- Tire rupture during installation and removal of tires and wheel components.
 - Ensure tire-wheel assemblies are fully deflated prior to mount-dismount. Run a wire down the valve stem to remove obstructions that would prevent full deflation.
 - Do not stand in the line of fire or trajectory zone when inflating tire.
 - Use appropriate restraining devices (i.e., tire cages) when inflating tires for inspection.

STANDARD OPERATING PROCEDURE

Repair of Tubeless BIAS Tires		Document Number: 960C-SOP-820
Original Approval Date: Feb 04, 2010	Revision Number: 5	Page 3 of 5
Latest Revision Date: Mar 28, 2025	Next Revision Date: Mar 28, 2028	Document Approval Level: 4

This document is not controlled if printed.

- Contact with foreign objects when deflating tires.
 - Do not stand in the line of fire, always stand to one side to avoid contact with dirt and debris.
- Noise exposure when deflating tires.
 - Wear hearing protection when deflating tires. Double hearing protection may be required for tires with super large bore or larger valve stems; alternatively a muffler may be used to reduce the noise.
- Uncontrolled work area.
 - Communicate with co-workers involved in the removal-installation process.
 - Keep work area clear of unnecessary personnel, erect barriers as required.
- Working with hazardous products / substances (liquid buffer, vulcanizing cement).
 - Use products in a well-ventilated area.
 - Avoid prolonged exposure to vapours; do not inhale vapours.
 - An air purifying respirator must be worn if product is to be used in areas with poor ventilation.
 - Review SDS and wear task appropriate PPE.
 - Do not use near heat, sparks, open flames, or hot surfaces.

4.0 CHECKLIST

- ☐ Attend all preparatory meetings (i.e. daily PSI; job scope; review of JSA's and SOPs for the job)
- ☐ Complete FLRA cards before starting the work.
- ☐ Ensure all personnel involved in the task are aware of the hazards and the controls to be used, as identified in the SOP's; JSA's; and FLRA's.
- ☐ Conduct a pre-job inspection of all equipment to be worked on and tools to be used.
- ☐ **Standard of Training required for working on this job: On-the job training.**

5.0 DEFINITIONS

5.1 Company

Means North American Construction Group Ltd. (NACG) and all directly or indirectly owned subsidiary companies, including joint ventures.

5.2 Company Personnel

Includes the Company's employees, officers, directors, agents, associates, consultants/contractors, temporary employees, and third-party processors.

5.3 HSE

Refers to the Health, Safety & Environment department.

STANDARD OPERATING PROCEDURE

Repair of Tubeless BIAS Tires		Document Number: 960C-SOP-820
Original Approval Date: Feb 04, 2010	Revision Number: 5	Page 4 of 5
Latest Revision Date: Mar 28, 2025	Next Revision Date: Mar 28, 2028	Document Approval Level: 4

This document is not controlled if printed.

6.0 PROCEDURE

- 1) Complete hazard assessment for task. Follow up with supervisor if unsure of tasks or if hazards cannot be controlled.
- 2) Conduct pre operation inspection of equipment. Notify supervision if equipment is damaged or defective.
- 3) Mark the sidewall of the tire with chalk or paint marker to indicate valve stem location prior to dismounting tire from wheel assembly.
- 4) Follow the appropriate Standard Operating Procedure (SOP) for dismounting the type of tire being repaired.
- 5) Clean and inspect the wheel, valve stems and all other hardware for cracks, wear and/or abnormalities, replacing damaged items as necessary.
- 6) Place the dismounted tire on a tire spreader if possible and inspect the entire casing for signs of run flat or other abnormalities and replace tire if beyond repair.
- 7) Adequately secure tire and inflate the tire to 20-30 psi. Monitor tire for noises or visual abnormalities.
- 8) If leak is difficult to identify, place the tire assembly in a dunk tank if available and observe for escaping air bubbles (tires up to medium truck only).
- 9) If dunk tank is not available, spray tire with soap and water solution and observe for escaping air bubbles.
- 10) If a leak is identified, mark the source with tire chalk or paint marker.
- 11) If the test indicates a valve or O-ring leak, replace defective item as required.
- 12) If damaged area is too large for repair in shop, take appropriate measures to send it out for possible section repair.
- 13) Mark the inner liner in a cross pattern with tire chalk or paint marker at the damaged area and note the appropriate size of BIAS patch required for repair.
- 14) Using the appropriate reamer, ream the damage area from the inside of the tire to accommodate the appropriate insert or uniseal patch.
- 15) When an insert or bias patch is used, lubricate the insert lightly with vulcanizing fluid (Refer to SDS) and pull through the reamed hole using an insert tool. Leave approximately 1/8" of the insert protruding through the inside of the tire casing.
- 16) If a bias patch only, is used, skip steps 12 & 13.
- 17) Buff the inner liner of the casing to accommodate the required size of patch.
- 18) Vacuum out or remove loose rubber or other foreign materials from inside casing.
- 19) Clean the buffed area with a liquid buffer. Refer to MSDS.
- 20) Apply a thin layer of the appropriate vulcanizing fluid over the buffed surface being careful not to let the fluid pool. Refer to MSDS.
- 21) Allow vulcanizing fluid to dry. Clean your hands before handling patches.

STANDARD OPERATING PROCEDURE

Repair of Tubeless BIAS Tires		Document Number: 960C-SOP-820
Original Approval Date: Feb 04, 2010	Revision Number: 5	Page 5 of 5
Latest Revision Date: Mar 28, 2025	Next Revision Date: Mar 28, 2028	Document Approval Level: 4

This document is not controlled if printed.

- 22) If a patch only, or a patch and insert are used, remove protective wrappers, and install in vulcanized area ensuring arrows of the bias patch are pointed toward the tire beads. Ensure the patch is centred over the damaged area.
- 23) Using a stitcher, stitch the patch in place while moving from the centre of the patch to the outer edge on one side. Return to the centre and stitch from the centre to the opposite side. Maintain even pressure with the stitcher.
- 24) Mount the tire back on the wheel ensuring the sidewall indication mark is lined up with the valve stem and follow the appropriate mounting Standard Operating Procedure for the type of tire being repaired.
- 25) Inflate tire to manufactures recommendations and check repaired area with soapy water to ensure the repair was successful.

7.0 NOTES

If this task is to be done by a method different than described in this SOP, the work must **STOP**, and the alternate method must be **DOCUMENTED** with an adequate hazard assessment tool such as a JSA. The document must be **APPROVED** by a supervisor before such procedures are implemented.

8.0 REFERENCES

- Alberta Occupational Health and Safety Act, Regulation and Code – Part 12, Section 193, Tire Servicing
- Alberta Occupational Health and Safety Act, Regulation and Code – Part 14, Sections 208 & 209, Lifting and Handling Loads
- Tire Industry Association Earth Mover Tire Service Training Program
- Equipment Manufacturer Service Manuals
- Jack Manufacturer's Operation Manual
- 960C-SOP-501 Rad Gun Use
- 960C-SOP-503 Hytorque Wrench; Use
- 960C-SOP-504 Hand Tools; Use of
- 960C-SOP-806 Manipulator Use to Remove and Install Tire-Wheel Assemblies
- 960C-SOP-824 Torqueing of Tire-Wheel Assemblies
- 950C-C-028 Hazardous Energy Isolation Code

9.0 APPENDICES

- No appendices